

MANUFACTURER:

SaverSystems

Richmond, IN 47374

800-860-6327

Fax: 765-935-4999

www.defywoodstain.com

DESCRIPTION

DEFY Wood Cleaner is a powdered concentrate that is mixed with water. It is an environmentally friendly product that safely cleans, brightens, and restores the natural beauty of exterior wood. This product also cleans weathered composite lumber, removing mold, mildew and algae along with the silver gray color that can develop over time. Restores wood and wood composites to their original appearance. DEFY Wood Cleaner is also an excellent choice for cleaning vinyl and aluminum siding as well. Unlike chlorine bleach based cleaners, DEFY Wood Cleaner is biodegradable and will not harm wood fibers, pets, grass, or most plants.

USES

DEFY Wood Cleaner removes dirt, grime, mildew stains, and weathered graying from horizontal and vertical wood surfaces. It is recommended for surface preparation prior to application or reapplication of clear finishes and stains. For best results use DEFY Wood Stains.

ADVANTAGES

- Restores the natural beauty of wood
- Contains no acid or chlorine bleach
- Safe for plants and animals
- Biodegradable

DIRECTIONS FOR USE

Limitations: DEFY Wood Cleaner will darken redwood. Use DEFY Wood Brightener to restore redwood to its original color or as a neutralizer to further brighten other wood species that have been cleaned with DEFY Wood Cleaner.

APPLICATION

Use 6 ounces (3/4 cup) of DEFY Wood Cleaner powdered concentrate with each gallon of water.

Mix with water and stir thoroughly until powder is mostly dissolved. Powder dissolves faster in warm water. Solution should be used within six hours of mixing.

Horizontal Surfaces: Dampen surface with water before application. Apply DEFY Wood Cleaner solution with sprayer, brush, or mop, working on small areas, (20-30 sq. ft.) at a time.

Vertical surfaces: Dampen surface with water before application. Apply with a sprayer working on small areas at a time. Begin at the bottom and work to the top

Horizontal Surfaces: Let solution stand approximately 15-20 minutes, keeping area wet with additional DEFY Wood Cleaner solution. Thoroughly scrub with a stiff, short bristle broom or brush.

Vertical Surfaces: Let solution stand approximately 15-20 minutes, keeping surfaces wet with additional solution. Thoroughly scrub with a stiff, short bristle broom or brush working from bottom to top. DEFY Wood Cleaner will open wood pores and some raising of wood fibers may occur.

Rinse thoroughly with water from hose or pressure washer using lowest pressure that cleans without damaging the wood. Repeat steps 2-4 on next small area. Rinse cleaned area of vertical surfaces to avoid streaking as work progresses. Allow wood surfaces to thoroughly dry before applying DEFY Wood Stains. Heavily weathered or soiled surfaces may require a second application.

While still wet after cleaning the entire project, neutralize wood by using DEFY Wood Brightener. This is an essential step before staining.

Coverage: Each gallon of diluted cleaner cleans and restores 100-200 sq. ft. depending on wood porosity.

CLEAN UP

Clean tools and equipment immediately after each use with soap and water.

CAUTIONS

Keep out of reach of children. Do not take internally. Avoid contact with eyes and mucous membranes and prolonged contact with skin. Avoid breathing mist. Close container tightly after each use. Do not re-use containers. Contains sodium carbonate peroxyhydrate. Do not mix with chlorine bleach or other chemicals. Store in original container only. Sweep up spills and flush down drain. Contact with combustible organic materials may cause fire. Accumulation of product on ladders, scaffolding, decks, etc., may result in a slippery surface.

FIRST AID

If inhaled: Move to fresh air.

If swallowed: Rinse mouth. Do NOT induce vomiting. Never give an unconscious person anything to drink. Immediately call a POISON

CENTER or doctor/physician. Oxygen and/or artificial respiration may be necessary..

For skin contact: Remove/Take off immediately all contaminated clothing. Wash off immediately with soap and plenty of water. Get medical attention if irritation persists.

For eye contact: Immediately flush eyes thoroughly with water for at least 15 minutes, including under the eyelids. Remove contact lenses, if present and easy to do. Continue rinsing. Seek medical attention immediately. In case of difficulty in opening lids, administer an analgesic eye wash (oxybuprocaine).

For additional information for this product, consult the Safety Data Sheet available at www.defywoodstain.com.

LIMITED WARRANTY

Our recommendations for use of this product are based upon tests believed to be reliable. Since field conditions vary widely, the user must determine the suitability of the product for the particular use and specific method(s) of application. Due to the fact that SaverSystems has no control over surface preparation and application methods, no guarantee as to results is offered, expressed or implied. SaverSystems warrants this product to be free from manufacturing defects.

SaverSystems' liability shall be limited in all events to supplying enough product to re-treat the specific areas to which defective product was applied. This warranty does not include the cost of labor application. SaverSystems shall not have any other liability including direct, incidental, or consequential damages. Some states do not allow the exclusion of incidental or consequential damages, so this limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

PACKAGING

Available in 2.25-lb. and 10-lb. recyclable plastic containers.

TRANSPORT AND HANDLING

DEFY Wood Cleaner is not considered hazardous under Department of Transportation regulations. Do not stack pallets. Store in cool, dry area.

PHYSICAL PROPERTIES

COLOR White
ODOR Odorless
SOLVENT Water
SHELF LIFE 24 months when unopened